

Franklin[®]

Electronic Publishers

For Use with the Franklin

Digital Book System[®]

IC-119



DIGITAL BOOK

KJV

HOLY BIBLE

KING JAMES VERSION

User's Manual

License Agreement

READ THIS LICENSE AGREEMENT BEFORE USING THE DIGITAL BOOK. YOUR USE OF THE DIGITAL BOOK DEEMS THAT YOU ACCEPT THE TERMS OF THIS LICENSE. IF YOU DO NOT AGREE WITH THESE TERMS, YOU MAY RETURN THIS PACKAGE WITH PURCHASE RECEIPT TO THE DEALER FROM WHICH YOU PURCHASED THE DIGITAL BOOK AND YOUR PURCHASE PRICE WILL BE REFUNDED. DIGITAL BOOK means the software product and documentation found in this package and FRANKLIN means Franklin Electronic Publishers, Inc.

LIMITED USE LICENSE

All rights in the DIGITAL BOOK remain the property of FRANKLIN. Through your purchase, FRANKLIN grants you a personal and nonexclusive license to use the DIGITAL BOOK on a single FRANKLIN Digital Book System at a time. You may not make any copies of the DIGITAL BOOK or of the data stored therein, whether in electronic or print format. Such copying would be in violation of applicable copyright laws. Further, you may not modify, adapt, disassemble, decompile, translate, create derivative works of, or in any way reverse engineer the DIGITAL BOOK. You may not export or re-export, directly or indirectly, the DIGITAL BOOK without compliance with appropriate governmental regulations. The DIGITAL BOOK contains Franklin's confidential and propriety information which you agree to take adequate steps to protect from unauthorized disclosure or use. This license is effective until terminated. This license terminates immediately without notice from FRANKLIN if you fail to comply with any provision of this license.

Contents

Getting Started	4
Viewing a Demo	6
Using the Menus	7
Finding Book, Chapter, Verse	9
Reading the Bible	11
Searching For Words	13
Searching for Phrases	16
Expanding Searches	18
Expanding Search Words	20
Picking Search Words	23
Viewing Footnotes	25
Using Bookmarks	27
Changing Settings	29
Sending Words	31
Digital Book System®	33
Specifications	36
Warranty	37
Key Guide	38
Index	39

Introduction

Congratulations! Your new Bible combines the majesty and poetry of the King James Version (KJV) with the latest technology from Franklin Electronic Publishers.

Using this Bible, you can. . .

- read any verse of the Old or New Testament,
- scan and read surrounding verses,
- search for words or phrases as you would in a concordance,
- pick and search for words from any verse,
- expand your searches,
- view footnotes and word counts,
- place up to 30 bookmarks,
- change type sizes and other settings, and
- look up Bible words in other digital books.

This User's Manual shows you how. You can use it as a tutorial or as a reference.


✓ Your First Tip

Throughout this User's Manual, you'll see tips about how to get the most from your new Bible. Look for them.

Getting Started

You must install the Bible digital book before you can use it. **WARNING:** Never install a digital book when the Digital Book System is on.

- 1. Turn the Digital Book System off.**
- 2. Install the Bible in a slot on the back.**



- 3. Press **ON/OFF** .**
- 4. To adjust the contrast, turn the wheel on the side of the Digital Book System.**
If the screen is still blank, check the batteries.

✓ **Protect Your Digital Books**

If you install or remove digital books while the Digital Book System is on, information that you entered in any installed digital book may be erased.

Getting Started

Once the Bible is installed, here is how to select and start using it.

1. Press **CARD** .
2. Press **→** or **←** to highlight the KJV Bible symbol.



3. Press **ENTER** .

Type a request, then press **ENTER**.

←

Press **MENU** for other options.

This is the Request Line of the Bible. You can always go to the Request Line by pressing **CLEAR**.


✓ Resuming Where You Left Off

When using the Bible, you can turn off the Digital Book System at any time. When you turn the Digital Book System on again, you'll return to the screen that you last viewed.

Viewing a Demo

Before using the Bible, you may want to view a demonstration of what it can do.

1. Press **MENU** .
2. Press **←** to highlight **View Demo** under **Other**.



3. Press **ENTER** .
4. To stop the demo, press **CLEAR** .

✓ Help is at Hand

Except while viewing the demo, you can view a help message at any screen by pressing **HELP** .

To scroll up or down, press **↓** or **↑** .

To page down, press **DN** or **SPACE** .

To go to the start or end of a message, hold **○** and press **↓** or **↑** .

To exit a help message, press **BACK** .

Using the Menus

Using the Old and New menus, you can select and view any book or section of the Bible. Try this example.


1. If you're not at the menus, press **MENU**.

2. Press **↔** to highlight **New**.



The flashing arrows show which arrow keys you can press at any screen.

3. Press **↓** to highlight **Romans**.



4. Press **ENTER** or **SPEC**.




5. Press **↓** to highlight a section.

Using the Menus



Sections: Romans
Keeping the Law
For All Have Sinned
Abraham Justified By Faith

6. Press **ENTER**.



CHAPTER 4
1 What shall we say then that
Abraham our father, as pertaining
to the flesh, hath found?
2 For if Abraham were justified by

7. Press **MENU** to return to the menus.

A check marks the book that you last read.

✓ Tips for Using Menus

- To go to the top or bottom of a menu, hold the gold key, **○**, while pressing **↑** or **↓**. For example, hold **○** and press **↓** under the Old menu to highlight *Malachi*.
- To go directly to the first verse of a book, highlight the book under the Old or New menu and then press **○** plus **ENTER**.
- To view the section menu of the current book when you're viewing verses, press **SPEC**. Then select and view another section.

Finding Book, Chapter, Verse






You can find any verse of the Bible by entering a book title, chapter number, and verse number at the Request Line. You should type a space or colon between the chapter and verse numbers. You don't need to type capital letters.

1. At the Request Line, type a book title, chapter number, and verse number.

Type a request, then press **ENTER**.

john 3 16

Press **MENU** for other options.

To type numbers, press  plus the numbered keys.* To type a space, press . To type a colon, press  plus . To erase characters, press .

2. Press .

16 ¶ For God so loved the world,
that he gave his only begotten Son,
that whosoever believeth in him
should not perish, but have ever-
lasting life. ↓

3. Press or to move down.

4. When you're done, press .

*If you're using a DBS-2D, simply press the number keys.

Finding Book, Chapter, Verse

✓ Tips for Finding Verses

- Type only a book title to find the first verse in a book. Type a book and chapter number to find the first verse in a chapter.
- Type abbreviations rather than full book titles (e.g., `ps` for Psalms or `eph` for Ephesians).
- Type an Arabic or Roman numeral before books of more than one volume (e.g., `1 samuel` or `II kings`).

✓ Ambiguous Requests

Some book titles are also words in the Bible. If you request one alone, you see a menu like this:



```
Pick Which Request Type 
Read From John
Search For "john"
```

To read the book, press . To search for the word, press and then .

✓ Understanding Sections

The section titles have been added by Franklin Electronic Publishers for your convenience. They are not part of the King James Version.

Reading the Bible



Once you've found a Bible verse, you can scan and view surrounding verses. The following example starts at Genesis 1:1.

1. Press **CLEAR** .

2. Press **ENTER** .

Genesis
CHAPTER 1
1 In the beginning God created the
heaven and the earth.
2 And the earth was without form,

3. Press  or  to scroll.

4. Press  or  to page down or up.
Or press **SPACE** to page down.


5. Press  plus  or  to go to
the end or start of the chapter.

6. Press  plus  or  to go to
the next or previous chapter.

CHAPTER 2
1 Thus the heavens and the earth
were finished, and all the host of
them.
2 And on the seventh day God ended

✓ Where in the Bible Are You?

Once at a verse, you can view its book, chapter, and verse number by pressing (?*).




3 And God blessed the seventh day,
and sanctified it because that in it
he had rest. **Genesis 2:3** is work
which God created and made.
4 ¶ These are the generations of

✓ Viewing Word Counts

Once at a verse, you can view the number of times a word occurs in the Bible.

First, press (ENTER) to start the highlight.
Then press the arrow keys to highlight a word.
Then press () plus (SPEC).



3 And God blessed the seventh day,
and sanctified it because that in it
he had rest. **62 occurrences** work
which God created and made.
4 ¶ These are the generations of

You cannot view the counts of the short, common words listed on p. 24.

Searching For Words

You can search for any word in the Bible, except the short, common words listed on p. 24. Simply enter up to four words at the Request Line. You'll find every occurrence, or match, of the word(s).

1. At the Request Line, type up to four words.

Type a request, then press **ENTER**.

meek

Press **FIND** for other options.

You don't need to type capital letters.

To erase letters, press **BACK**.

2. Press **ENTER**.

3 (Now the man Moses was very
◆meek◆, above all the men which
were upon the face of the earth.)
4 And the LORD spake suddenly unto
Moses, and unto Aaron, and unto

The diamonds mark the first match.

3. Press **DOWN** plus **DOWN** to view the next match.

26 The ◆meek◆ shall eat and be
satisfied: they shall praise the
LORD that seek him: your heart
shall live for ever.
27 All the ends of the world shall

To view the previous match, press **DOWN** plus **UP**.

Searching For Words

4. Press **(MENU)** .



5. Press the arrow keys to highlight a book under **Old** or **New**.

6. Press **(ENTER)** and then select a section with matches.

7. To clear the search, press **(CLEAR)** .

✓ Understanding Menus

After a word search, the Old and New menus and section menus list only those books and sections containing matches of your search words. The last book or section that you read is checkmarked.

To view full book and section menus, clear your search by pressing **(CLEAR)**. Then press

(MENU) .





Searching For Words

✓ If You Misspell a Word

When you request a misspelled word, or a correctly spelled word that is not in the Bible, you see a correction list like this:



A screenshot of a correction list displayed in a monospaced font. The first word, 'mercy', is highlighted with a black background. Below it are the words 'mercies', 'Meres', 'Meroz', and 'marishes'.




Press  or  to highlight a correction and then press . Or press  to edit your request.

✓ If No Matches Are Found

When you request two or more words that have no exact matches, you see this menu:



A screenshot of a menu displayed in a monospaced font. The first option, 'No Matches Found', is highlighted with a black background. Below it are the options 'Search for Similar Words' and 'Edit Your Request'.


To search for similar words (i.e., inflections and synonyms), press . To edit your request, press  and then .

Searching for Phrases

Using the Search menu, you can select an ordered search and then narrow the search width so that you can find phrases. An ordered search finds words in the order that you request them. You can make these selections before or after a word search.

1. Press **(MENU)** .

2. Press the arrow keys to highlight **Ordered Search** under **Search**.




Italicized items can't be used now.

3. Press **(ENTER)** .

A check marks your selection. You can deselect it by pressing **(ENTER)** again.

4. Press **(↓)** to highlight **change Search Width**.

5. Press **(ENTER)** .



Searching for Phrases

6. Press  to highlight `Close Together`.
Then press .

7. Type a phrase.

Type a request, then press .

`holy spirit`

Press  for other options.

8. Press .

✓ Understanding Ordered Searches

Remember, ordered searches find words only in the order in which you request them.

For example, an ordered search for `holy spirit` will not find `spirit holy`.

✓ Understanding Search Widths

The search width is how far apart your words can be in matches. Here are what the widths mean:

`Close Together` : search words adjacent or nearly adjacent

`Not as Close` : a few words apart

`Far Apart` : many words apart

`Very Far Apart` : a few verses apart.


Expanding Searches

To find more matches, you can expand a word search up to three times. Each expansion adds related words to your word search. Try this example.

1. At the Request Line, type `belief`.
2. Press **(ENTER)** to view the first match.
3. Press **(MENU)**.
4. Press the arrow keys to highlight `Expand Search` under `Search`.




5. Press **(ENTER)**.



The number of books with matches increases.

6. Press **(ENTER)** two more times to fully expand the search.

Expanding Searches



7. Press the arrow keys to highlight a book under the Old or New menu.
8. Press **(ENTER)** and then select a section with matches.

✓ Unexpanding Searches

To unexpand an expanded word search, first press **(MENU)**. Then press the arrow keys to highlight the Unexpand Search item under the Search menu. Then press **(ENTER)**.

✓ A Quick Way to Expand Searches


Rather than using the Expand Search item under the Search menu, simply press **(MORE)** up to three times to expand a word search. After a word search, you can press **(MORE)** when Bible verses or the Old and New menus are in view.

To quickly unexpand an expanded word search, press **(O)** plus **(MORE)**.


Expanding Search Words

When you search for more than one word, you can expand and then unexpand each word separately to fine-tune a word search.


1. At the Request Line, type `creation god`.
2. Press **ENTER** .
3. Press **MENU** .



4. Press the arrow keys to highlight `Expand a Word` under `Search`.



5. Press **ENTER** .



6. Press **ENTER** to expand `creation`.

Expanding Search Words

The number of matches increases.

7. Press **ENTER again to fully expand the word.**

If you press **ENTER** again, you see a message that no more expansion is possible.

8. Press **BACK.**

9. Press the arrow keys to highlight a book under the Old or New menu.

10. Press **ENTER and then select a section with matches.**

✓ Unexpanding Search Words

You can unexpand expanded words in a multiple-word search by highlighting the Unexpand a Word item under the Search menu. Then press **ENTER**. Then highlight a search word to unexpand. Then press **ENTER**.

Only an expanded search word can be unexpanded. You can unexpand a fully expanded search up to three times.

✓ Understanding Expansion Levels

When you expand a search word, you see a message showing the current expansion level.

A screenshot of a search interface. At the top, it says "Pick a Word to Expand" followed by a text input field. Below that, there are two "Expand" buttons. The first "Expand" button is highlighted with a thick black border, and next to it, a box displays "Expansion Level 2".

Pick a Word to Expand
Expand **Expansion Level 2**
Expand

There are four expansion levels. Each level adds related words to your search.

Expansion Level 1 is the unexpanded search word (e.g., belief) alone. Level 2 adds inflections (e.g., believe and believed). Level 3 adds compound and related words (e.g., believer and unbelief). Level 4 adds synonyms (e.g., understand and obeyed).

If an expansion level adds no words, the expansion automatically moves to the next level. For that reason, many words are fully expanded to Level 4 after less than three expansions.

Picking Search Words

You can also search for a word by highlighting, or picking, it from a Bible verse. You can pick and search for any word except the short, common words listed on p. 24. Try this example.

1. At the Request Line, type `romans 5 6`.
2. Press **ENTER** to find the verse.
3. Press **ENTER** to start the highlight.

```
6 For when we were yet without
strength, in due time Christ died
for the ungodly,
7 For scarcely for a righteous man
will one die: yet peradventure for a
```

You can turn off the highlight by pressing **BACK**.

4. Press the arrow keys to highlight `righteous`.

```
6 For when we were yet without
strength, in due time Christ died
for the ungodly,
7 For scarcely for a righteous man
will one die: yet peradventure for a
```


5. Press **ENTER** to search for matches.

```
Come thou and all thy house into
the ark; for thee have I seen
●righteous● before me in this gen-
eration.
2 Of every clean beast thou shalt
```


Picking Search Words

6. Press  plus  to view the next match.

23 ¶ And Abraham drew near, and
said, Wilt thou also destroy the
righteous with the wicked?
24 ¶ Peradventure there be fifty
righteous within the city: wilt thou ↓

7. Press  to view the books with matches under the Old and New menus.

✓ Words Too Common to Search


You cannot search for these words because they are too common:


a, an, and, are, as, be, but, by, for, from, he, her, him, his, I, in, it, me, my, not, O, of, our, out, shall, shalt, she, that, the, thee, their, them, they, thou, thy, to unto, up, upon, us, was, we, were, with, ye, you.

✓ Understanding Verse Markings

Verse numbers are at the left in boldface type. The ¶ marks paragraphs. Italics indicate words added by the original translators of the King James Bible. Horizontal lines, ———, mark the end of chapters, footnotes, and help.

Viewing Footnotes

When you see a  in a verse, a footnote about archaic English usage exists. To learn how to view footnotes, follow this example.

1. At the Request Line, type `psalm 16 7`.
2. Press .

```
7 I will bless the LORD, who hath
given me counsel: my reins¶ also
instruct me in the night seasons.
8 I have set the LORD always
before me: because he is at my
```

Notice the footnote symbol, , after `reins`.

3. Press  plus .

```
reins or kidneys here refers to
the seat of the affections, corre-
sponding to heart or soul in mod-
ern English.
```




4. Press  to go back to the verse.



✓ Understanding Footnotes

The footnotes in this Bible have been added by Franklin Electronic Publishers to clarify the meaning and usage of archaic English words. These footnotes are not part of the King James Version.





Viewing Footnotes

✓ When More Than One Note Appears

When more than one  appears on screen, press  plus  to view the footnote nearest the top.

To view other footnotes on screen, first press  to start the highlight. Then press the arrow keys to highlight another .

15 Neither do men light a candle^N,
and put it under a bushel, but on a
candlestick^N, and it giveth light
unto all that are in the house.
16 Let your light so shine before †

Next, press  plus , or simply , to view the note. Once you've read the footnote, press  to go back to its verse.

Using Bookmarks

For quick reference, you can place up to 30 bookmarks in the Bible. Then you can scan your bookmark list and view any marked verse. In this example, we'll place a bookmark at Matthew 5:3.

1. Type `matthew 5 3`. Then press **ENTER**.
2. Press **LIST**.

```
Add Matthew 5:3
John 3:16
Exodus 20:2
Psalms 23:1
```

This is a sample bookmark list. Yours will vary.

3. Press **ENTER** to add a bookmark.

```
Ⓜ3 Blessed are the poor in spirit:
for theirs is the kingdom of heav-
en.
4 Blessed are they that mourn: for
they shall be comforted. ↓
```

The bookmark, **Ⓜ**, is placed at the top verse.

4. Press **LIST** again.
 - To delete the bookmark that you just added, press **ENTER**.
 - To view a marked verse, press **↓** to highlight it. Then press **ENTER**.

Using Bookmarks

✓ A Quick Way to Place Bookmarks

Rather than pressing **LIST** and then **ENTER** to place a bookmark at a verse, simply press **○** plus **(M)**.

✓ Deleting Bookmarks

To delete a bookmark from your bookmark list, follow these steps.

1. Press **LIST** .
2. Press **↓** to highlight a verse.
3. Press **○** plus **(D)** delete its bookmark.

To delete all your bookmarks, press **CLEAR** plus **ON/OFF** . CAUTION: When you delete all your bookmarks, the menus return to their original (i.e., factory default) settings.


✓ Understanding Bookmarks

Your bookmarks are listed from oldest (top) to newest (bottom). When you view your bookmark list from a verse, the top line lets you add or delete a bookmark at the current verse.


Changing Settings

Using the Other menu, you can change the type size and the shutoff time at any time. Here is how.

1. Press **(MENU)**.
2. Press the arrow keys to highlight **Set Type Size** under **Other**.



3. Press **(ENTER)**.



4. Press **(↓)** or **(↑)** to highlight a type size.
To keep the current size, press **(BACK)**. Then go to Step 7.
5. Press **(ENTER)** to select it.
6. Press **(MENU)**.
7. Press the arrow keys to highlight **Set Shutoff** under **Other**.

Changing Settings

8. Press **ENTER** .



9. Press **↓** or **↑** to highlight a time.

10. Press **ENTER** to select it.

✓ Understanding Times and Sizes

- The shutoff time is how long the Bible stays on when you forget to turn it off.
- The type size is how large the letters appear in verses, messages, and the Request Line. if you normally read large-print books, pick **Large** Or **Very Large**

✓ Backing Up

Remember, you can back out of the Pick a Type Size or Pick a Shutoff Time menu without changing settings by pressing **BACK** .

Sending Words

The Bible can send and receive words to and from certain digital books such as dictionaries and encyclopedias. In this example, we'll look up a word from the Bible in the Concise Columbia Encyclopedia (IC-114).

1. Type `luke 18 31`. Then press **ENTER**.
2. Press **ENTER** again.
3. Press the arrow keys to highlight `Jerusalem`.

```
31 ¶ Then he took unto him the
twelve, and said unto them, Behold,
we go up to Jerusalem, and all
things that are written by the
prophets concerning the Son of man
```

4. Press **○** plus **CARD**.
5. Press **←** or **→** to highlight the Columbia Encyclopedia symbol.
6. Press **ENTER**.

Jerusalem appears in the Request Line of the Encyclopedia.



7. Press **ENTER**.

```
Jerusalem, city (1986 est. pop.
468,900), capital and largest city
of Israel, on a high ridge W of the
Dead Sea and the Jordan R. A holy
```


8. Press  to read the entry.

✓ Comparing Translations


If you install the King James Version and another Bible such as the New International Version (IC-121) in your Digital Book System, you can easily compare translations. Here's how:

1. At a verse in either Bible, press  plus .

2. Highlight the symbol of the other Bible.



3. Press .

The book, chapter, and verse number appear in the Request Line of the other Bible.

4. Press  to view the verse.

To return to the same verse in the first Bible, repeat these steps.

✓ Receiving Words

The Bible can also receive words from other digital books (e.g., the Columbia Concise Encyclopedia). To send a word to the Bible, first highlight a word in the other book. (Read its User's Manual to learn how.) Then press  plus  and select the Bible symbol.

Digital Book System®

This section reviews key features of the Digital Book System.

Resetting the Digital Book System

If the keyboard fails to respond or the screen performs erratically, first press **CLEAR** and then press **ON/OFF**. If nothing happens, hold **CLEAR** and press **ON/OFF**. If still nothing happens, press the recessed reset button on the back of the Digital Book System using a paper clip.

Sending Words Between Books

Some digital books can send and receive words from other digital books.

1. Highlight a word in a digital book.

Read its User's Manual to learn how.

2. Hold and press **CARD**.

3. Press or to highlight a book symbol.

4. Press **ENTER**.

The first screen of the selected digital book appears.

5. If needed, press **ENTER** again to look up the word.

Replacing the Batteries

The Digital Book System uses CR2032 lithium batteries. CAUTION: Have new batteries ready before following these steps.

1. Turn the Digital Book System off.
2. Press and slide the battery cover off the back of the unit. Then remove all the batteries.
3. Place a battery, with its plus (+) sign up, at the bottom of each battery cavity.
4. Place a battery, plus sign up, at the top of each cavity. The metal clip must contact the top battery.
5. Replace the battery cover

✓ Battery Warnings

To avoid deleting information from your installed digital books:

- Replace batteries before they lose all power.
- Once batteries have been removed, install new ones within two minutes.
- Don't mix old and new batteries.
- Never remove batteries with the unit on.

Protection and Storage

- Don't touch the metal contacts on the back of your digital books or the rubber contacts in the book slots of the Digital Book System. **CAUTION:** Touching the contacts with statically charged objects, including your fingers, could erase information that you entered in your installed digital books.
- Don't put excessive pressure or weight on your digital books or Digital Book System.
- Don't expose your digital books to extreme or prolonged heat, cold, or other adverse conditions.

When you're not using your Digital Book System, keep digital books or dummy books in its slots to prevent dust build-up.

Cleaning

To clean the digital books, apply isopropyl alcohol with cotton swab.

To clean the Digital Book System, apply a mild household cleaner onto a soft cloth. **CAUTION:** Spraying liquids directly on your Digital Book System could damage its circuitry.

Specifications

Model IC-119

- Old and New Testaments, King James Version
- Two search methods: (1) by book, chapter, and verse, and (2) by search word(s)
- Pick mode, word search expansion/unexpansion, and search word expansion/unexpansion
- Word order and search width settings
- Word counts and section menus
- Book, chapter and verse reminders
- Spelling correction
- Up to 30 bookmarks
- Usage footnotes
- Adjustable type size, shutoff time, and contrast
- Context-sensitive help messages
- Size: 2-1/4" x 1-1/4" x 1/4"

Copyrights, Trademarks, and Patents

© 1989-1993 Franklin Electronic Publishers, Inc. Mt. Holly, N.J., 08060 U.S.A. All rights reserved. Scripture taken from the Holy Bible, King James Version. Digital Book System is a registered trademark of Franklin.

Patents: 4,490,811; 4,982,181; 5,113,340; 5,153,831; 5,153,831; DES.321,366. European Patent: 0 136 379. Patents Pending

ISBN 1-56712-036-9

Limited Warranty (USA only)

FRANKLIN warrants to you that the DIGITAL BOOK will be free from defects in materials and workmanship for one year from purchase. In the case of such a defect in your DIGITAL BOOK, FRANKLIN will repair or replace it without charge on return, with purchase receipt, to the dealer from which you made your purchase or Franklin Electronic Publishers, Inc., 122 Burrs Road, Mt. Holly, NJ 08060, within one year of purchase. Alternatively, FRANKLIN may, at its option, refund your purchase price. Data contained in the DIGITAL BOOK may be provided under license to FRANKLIN. FRANKLIN makes no warranty with respect to the accuracy of data in the DIGITAL BOOK. No warranty is made that the DIGITAL BOOK will run uninterrupted or error free. You assume all risk of any damage or loss from your use of the DIGITAL BOOK. This warranty does not apply if, in the sole discretion of FRANKLIN, the DIGITAL BOOK has been tampered with, damaged by accident, abuse, misuse, or misapplication, or as a result of service or modification by any party, including any dealer, other than FRANKLIN. This warranty applies only to products manufactured by or for FRANKLIN. Batteries, corrosion or battery contacts and any damage caused by batteries are not covered by this warranty. NO FRANKLIN DEALER, AGENT, OR EMPLOYEE IS AUTHORIZED TO MAKE ANY ADDITIONAL WARRANTY IN THIS REGARD OR TO MAKE ANY MODIFICATION OR EXTENSION OF THIS EXPRESS WARRANTY.











THE FOREGOING WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ALL OTHER EXPRESS OR IMPLIED WARRANTIES, WRITTEN OR ORAL, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. YOUR SOLE AND EXCLUSIVE REMEDY SHALL BE FRANKLIN'S OBLIGATION TO REPLACE OR REFUND AS SET FORTH ABOVE IN THIS WARRANTY. Some States do not allow the exclusion of implied warranties, or limitations on how long a warranty lasts. This warranty gives you specific rights; you may also have additional rights which vary from State to State. This warranty shall not be applicable to the extent that enforcement of any provision may be prohibited by applicable law.

FRANKLIN SHALL IN NO EVENT BE LIABLE TO YOU OR TO ANY OTHER PERSON FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, OR ANY OTHER INDIRECT LOSS OR DAMAGE, ARISING OUT OF YOUR PURCHASE, THE MANUFACTURE OR SALE OF THE DIGITAL BOOK, THIS LICENSE, OR ANY

OBLIGATION RESULTING THEREFROM OR THE USE OR PERFORMANCE OF THE DIGITAL BOOK UNDER ANY LEGAL THEORY, WHETHER BREACH OF CONTRACT, TORT, STRICT LIABILITY OR ANY OTHER CAUSE OF ACTION OR PROCEEDING, WHICH DAMAGES SHALL INCLUDE, BUT NOT BE LIMITED TO, LOST PROFITS, DAMAGES TO PROPERTY, OR PERSONAL INJURY (BUT ONLY TO THE EXTENT PERMITTED BY LAW). FRANKLIN'S ENTIRE LIABILITY FOR ANY CLAIM OR LOSS, DAMAGE, OR EXPENSE FROM ANY SUCH CAUSE SHALL IN NO EVENT EXCEED THE PRICE PAID FOR THE DIGITAL BOOK. THIS CLAUSE SHALL SURVIVE FAILURE OF AN EXCLUSIVE REMEDY.

This license and warranty is governed by the laws of the United States and the State of New Jersey.

Key Guide

- BACK** Back up; erase; or stop highlight in verses.
- CARD** Exit the Bible.
- CLEAR** Clear a request.
- ENTER** Enter a request; select items; start highlight.
- HELP** View a help message.
- LIST** View the bookmark list.
- MENU** View to and from menus.
- MORE** Expand a word search.
- ON/OFF** Turn the Digital Book System on or off.
- SHIFT** Shift keys.
- SPACE** Type a space; or page down.
- SPEC** View a section menu.
- CARD** Send word/verse between digital books.
- D** Delete a bookmark from the list.
- ENTER** Go to verses from the Old or New menu.
- M** Place a bookmark at a verse.
- MORE** Unexpand an expanded word search.
- N** View a footnote.
- Q** etc. Type numbers.
- SPEC** View word count of a highlighted word.
-     Move in indicated direction.
-   Page up or down.
- CARD**   Go to start/end of menu or chapter.
- CARD**   Go to next/previous chapter or match.
- ?*** View the book, chapter, verse number at a verse.

Index

? key 12

⊕ symbol 13

↑ symbol 24

☒ symbol 27

☒ symbol 25-26

Ambiguous requests 10

Arrows 7, 11

Auto-resume 5

BACK key 6, 9, 23, 30

Batteries, replacing 34

Bookmarks

deleting 28

placing 27-28

viewing 27

CARD key 5, 32

Check marks 8, 16

CLEAR key 5

Contrast, adjusting 4

Comparing verses 32

Copyrights, Trademarks,
and Patents 36

Demonstration 6

Digital Book System

cleaning 35

protecting 35

resetting 33

Digital books, installing 4

DN key 11

Erasing characters 9

Expanding

search words 20

searches using menus 18

searches using MORE 19

Expansion levels 22

Finding

books/sections using
menus 7

books/sections using
requests 9, 10

Genesis 1:1 11

phrases 16

verses 9

words 13

words by picking them 23

words from other books 32

words in other books 31

Footnotes 25

GOLD+CARD 31

GOLD+DN 11, 13

GOLD+ENTER 8

GOLD+M 28

GOLD+MORE 19

GOLD+N 25

GOLD+SPEC 12

GOLD+UP 11

HELP key 6

Highlighting

digital book symbols 5

footnotes in verses 26

turning off 23

words for word counts 12

words to search 23

Installing digital books 4

Index

Italics

in menus 16

in verses 24

LIST key 27

MENU key 6, 7

Menus

section 7

viewing 6

zooming up and down 8

MORE key 19

New menu 7

No Matches menu 15

Old menu 7

ON/OFF key 4

Ordered searches 16, 17

Other menu 6, 29

Phrases, finding 16-17

Pick a Width menu 16

Pick a Shutoff Time

menu 30

Pick a Type Size menu 29

Pick a Word to Expand

menu 20

Pick Which Request Type

menu 10

Request line 5

Screen contrast 4

Search menu 18

Search width 16, 17

Searches

expansion levels 22

ordered 16

picking words in verses 23

too common words 24

Sections 10

Sending

verses 32

words 31-32

SHIFT key 9

Shutoff time 29, 30

SPACE key 6, 9

SPEC key 7, 14

Specifications 36

Spelling correction 15

Type size, changing 29

Typing

abbreviations 10

colons 9

numbers 9

spaces 9

Unexpanding

search words 21

searches 19

UP key 11

Viewing

book, chapter, verse no.12

bookmark list 27

demo 6

footnotes 25

help messages 6

menus 6, 7

section menus 7, 8

verses 11

word counts 12

Warranty 37

Franklin[®]
Electronic Publishers
Mt. Holly, NJ 08060