Franklin®
Electronic Publishers

For Use with the Franklin
Digital Book System

IC-116

DIGITAL BOOK™

ADVANCED DICTIONARY

User's Manual

License Agreement

READ THIS LICENSE AGREEMENT BEFORE USING THE DIGITAL BOOK. YOUR USE OF THE DIGITAL BOOK DEEMS THAT YOU ACCEPT THE TERMS OF THIS LICENSE. IF YOU DO NOT AGREE WITH THESE TERMS, YOU MAY RETURN THIS PACKAGE WITH PURCHASE RECEIPT TO THE DEALER FROM WHICH YOU PURCHASED THE DIGITAL BOOK AND YOUR PURCHASE PRICE WILL BE REFUNDED. DIGITAL BOOK means the software product and documentation found in this package and FRANKLIN means Franklin Electronic Publishers, Inc.

LIMITED USE LICENSE

All rights in the DIGITAL BOOK remain the property of FRANKLIN. Through your purchase, FRANKLIN grants you a personal and nonexclusive license to use the DIGITAL BOOK on a single FRANKLIN Digital Book System at a time. You may not make any copies of the DIGITAL BOOK or of the data stored therein, whether in electronic or print format. Such copying would be in violation of applicable copyright laws. Further, you may not modify, adapt, disassemble, decompile, translate, create derivative works of, or in any way reverse engineer the DIGITAL BOOK. You may not export or re-export, directly or indirectly, the DIGITAL BOOK without compliance with appropriate governmental regulations. The DIGITAL BOOK contains Franklin's confidential and propriety information which you agree to take adequate steps to protect from unauthorized disclosure or use. This license is effective until terminated. This license terminates immediately without notice from FRANKLIN if you fail to comply with any provision of this license.

Contents

Getting Started 4

Install the Digital Book 5

Select the Dictionary 6

Select Other Options 7

Learn the Keys 8

Looking Up Words 10

Correcting Spellings 11

Finding Spellings 12

Finding Definitions 15

Finding Thesaurus Entries 18

Finding Classmates™ 21

Finding Confusable Words 22

Reviewing Words 23

Words From Other Books 24

Using Grammar Guide 26

Finding Topics 27

Grammar Exercises 29

Digital Book System 32

Index 39

Introduction

You now have a powerful electronic reference with the features of a dictionary and a thesaurus.

Using the *Merriam-Webster ®Advanced Dictionary*, you can:

- check and correct spellings,
- find unknown letters and fragments of words,
- find extensive definitions, word histories, and confusable word lists,
- find thesaurus meanings, synonyms, antonyms, and more,
- pick and look up words on screen,
- review words that you've already looked up,
- look up words from other digital books.

This User's Manual shows you how. You can follow its numbered instructions using the examples shown or using words that interest you.

About User Notes

Throughout this User's Manual, notes like this provide tips and explain advanced uses of *the Merriam-Webster® Advanced Dictionary*. Look for them.

Getting Started

If you're using
The *Merriam-Webster ®*
Advanced Dictionary
for the first time,
read this section.

Install the Digital Book

You must install the *Merriam-Webster® Advanced Dictionary* before you can use it.

1. Make sure the Digital Book System is off.

2. Insert the digital book in a slot on the back.



Line up the digital book's tabs with the notches in the slot. Then snap the digital book in place.

3. Press ON/OFF .

4. To adjust screen contrast, turn the contrast wheel on the side of the Digital Book System.

5. If the screen is blank, check the batteries.

Protect Your Digital Books

Never install or remove a digital book while the Digital Book System is on. If you do, information that you entered in the other installed digital book may be erased.

Select the Dictionary

Once the *Merriam-Webster® Advanced Dictionary* is installed, here's how to select and start using it.

1. Press (CARD) .

2. Press ⇦ or ⇨ to highlight the *Merriam-Webster® Advanced Dictionary* symbol.

3. Press (ENTER) .

This is the entry line. You can always return to it by pressing (CLEAR) .

Resuming Where You Left Off

If the Digital Book System is turned off while you're using the *Merriam-Webster® Advanced Dictionary*, simply press (ON/OFF) to return to the previous screen.

Select Other Options

Using the Other menu, you can select fonts, set shutoff times, and see a demonstration.

1. Press (MENU). Then press ⇨.

2. Press ⇩ to highlight an option.

3. Press (ENTER) to see the settings, if any.

4. Press ⇩ to highlight a setting.

5. Press (ENTER) to select it.

Understanding the Other Options

Run Demo shows you a brief demonstration. To stop the demo, press (CLEAR).

Select Font lets you decide how you want the letters to appear on screen. For easier reading, select a medium or large typeface.

Set Shutoff lets you set how long the Digital Book System stays on when you forget to turn it off.

Learn the Keys

Here are some of the keys you'll often use in the *Merriam-Webster® Advanced Dictionary*.

Function Keys

CLEAR	Clear to the entry line.
MENU	See the main menu.
MORE	Cycle through references.
GAMES	See grammar exercises.
LIST	Show the path list.
CARD	Switch to another digital book.
ENTER	See a definition or pick a word.
BACK	Back up or erase letters.
HELP	See a help message.

Direction Keys

⇦ ⇨	Move the cursor left or right.
⇧ ⇩	Move up or down.
UP DN	Page up or down.
⬭ + ⇧ ⇩	Zoom to the top or bottom of an entry.
⬭ + UP DN	Go to next or previous entry.

Gold Key Combinations

[gold] + C	See Classmates.
[gold] + D	Show dictionary definitions.
[gold] + T	See thesaurus meanings.
[gold] + ?*	Show Confusables.
[gold] + G	Go to the Grammar Guide.

MatchMaker™ Key

?*	Letter Detective™, find letters in words.
SHIFT + ?*	Fragment Finder™, find fragments of words.

Help is Always at Hand

To...	Press...
See a help message at any time	HELP
Move down the message	⇩
Exit the message	BACK

Looking Up Words

This section shows
you how to find
definitions, thesaurus entries,
and other information
about words.

Correcting Spellings

To check or correct spellings, simply type a word and press (ENTER). If you misspell a word, you'll see a correction list.

1. Press (CLEAR).

2. Type a misspelled word.

To erase letters, press (BACK).

3. Press (ENTER) to see a correction list.

4. To define a word, press ⇩ to highlight it. Then press (ENTER).

To go back to the correction list, press (BACK).

5. Press (CLEAR) when you're finshed.

Finding Spellings

You can find unknown letters, prefixes, suffixes, or fragments of words by using the MatchMaker™ characters—the question mark and the asterisk.

Letter Detective™

The question mark is the letter detective. It finds unknown letters in words.

1. At the entry line, type a word with a ? standing for each unknown letter.

2. Press (ENTER).

3. To define a word, press ↓ to highlight it. Then press (ENTER).

4. Press (CLEAR) when you're finished.

Fragment Finder™

The asterisk is the fragment finder. It finds prefixes, suffixes, and fragments of words. Each asterisk can stand for any number of letters.

1. Type a word with an ✻ standing for a series of unknown letters.

To type the asterisk, press (SHIFT) plus [?*].

2. Press (ENTER).

3. To define a word, press [⇩] to highlight it. Then press (ENTER).

4. Press (CLEAR) when you're finished.

Spelling Finder Tips

● You can enter ?'s and ✻'s in the same word. For example, `pers?ver*` . But don't place a ? next to an ✻. Remember, ✻'s can stand for any number of letters, including one or none.

● You can use ?'s and ✻'s to find unusual words. For example, to find two-letter words beginning with an O, enter o? . To find all words beginning with O, enter o✻.

● You can use ?'s to help solve crossword puzzles. For example, if the second letter of a five-letter word is H and its last letter is W. Enter `?h??w` to see possible answers.

Follow the Arrows

Blinking arrows on screen show which keys you can press to see more. Look for them.

Finding Definitions

You can find definitions in two ways: (1) by entering a word at the entry line, or (2) by picking a word from definitions or word lists.

By Entering Words

The simplest way to define words is to enter them at the entry line.

1. Type a word.

2. Press ENTER.

This is a dictionary entry. For information about understanding an entry see p. 17.

3. To move down the entry, press ⇩ or DN.

Read the next section for another way to find definitions.

By Picking Words

You can define words by picking them from definition or word lists. Word lists are always in pick mode.

1. At a definition, thesaurus meaning or grammar guide text, press (ENTER).

Or, under `Commands` , select `Pick Mode` . Then press (ENTER). To turn off the highlight, press (BACK).

2. Press the arrow keys to highlight a word.

3. Press (ENTER).

4. Press (CLEAR) when you're finished.

Seeing MORE Information

By pressing (MORE), you can instantly cycle from definitions to thesaurus entries to confusable words (if any) to Classmates (if any) and then back to definitions. You can start at any point in the cycle.

Understanding Dictionary Entries

In dictionary entries, the entry word (in bold) appears first with hyphenation points and part(s) of speech (in parentheses). One or more definitions of the entry word follow.

Some dictionary entries also contain derivative words (in bold), examples of usage (in brackets), synonyms (in **SMALL CAPS**) or an etymology (in brackets).

Browsing Dictionary Entries

You can browse through dictionary entries as you would in a book. At a definition, press plus ⇩ to see the next dictionary entry. Press plus ⇧ to see the previous one. Dictionary entries aren't always in alphabetical order.

Finding Thesaurus Entries

You can find thesaurus entries 1) by typing a word or, 2) by picking a word.

1. Type a word or pick one using pick mode.

2. Press [2nd] plus [T] .

This is a thesaurus entry. For more information, see “Understanding Thesaurus Entries” on p. 19.

3. Press [↓] to see synonyms, antonyms (if any), and Compares™ (if any).

Understanding Thesaurus Entries

Thesaurus entries consist of thesaurus meanings, synonyms, antonyms, or Compares™.

A **thesaurus meaning** is a definition shared by a group of synonyms.

Synonyms are words which have similar meanings to the word being defined.

Antonyms are words which have the opposite meaning of the word being defined.

Compares™ are words which are close in meaning to the word you looked up, but not close enough to be considered synonyms. They will often have a number after them, like "admire 1 " on the previous page. This number stands for the thesaurus entry of "admire " that is relevant to its usage as a Compare in the thesaurus meaning of "appreciate ".

Using Pick Mode in Thesaurus

Don't forget that you can always use pick mode. Press (ENTER) to turn it on. Then highlight a word and press + (T) to see it thesaurus meaning or (ENTER) to see is dictionary definition.

Using the Commands Menu

You can use the Commands menu to view dictionary entries, thesaurus entries, Classmates, Confusables™, the Grammar Guide, the Path List, and select Pick Mode. Simply type a word at the entry line and then press (MENU).

Next, press ⇩ to highlight a function. Then press (ENTER). Use ⇩ to see more functions.

You can press (MENU) at any screen except help messages to see any information that is available for a word. This will also work for a word highlighted via pick mode. Information is available for a word if it is in normal type. There is no information available if a menu topic is in italics.

Moving to the Thesaurus

You can always press ▭ + (T) to get to a thesaurus entry from a definition, Confusable words, or Classmates screen.

Finding Classmates™

Classmates are words classified by subject. Here's how to find a word's classmates if it has any.

1. Type a word or use pick mode to select one.

2. Press [2nd] plus [C].

This is the Classmates screen.

3. Press [CLEAR] when you're finished.

Two Ways Back Up

[BACK] takes you back to the previous screen.

[2nd] plus [DN] takes you back to the preceding screen of similar information. For example, if you're viewing a definition you go back the previous one.

Finding Confusable Words

Confusable words are homonyms and spelling variants that are easy to confuse. If a word has confusable words, you can find them (1) by entering the word and pressing [2nd] + [?*], or (2) by highlighting a word to pick it then pressing [2nd] + [?*].

1. At the entry line, type `heir`.

2. Press [2nd] plus [?*].

Each confusable is followed by an identifying word.

3. Press [↓] to highlight a word.

4. Press [ENTER] to define it.

To see Classmates, press [2nd] + [C]. To see thesaurus meaning, press [2nd] + [T]. Or, press [MENU] to see other options.

5. Press [CLEAR] when you're finished.

Reviewing Words

You can review words you've previously looked up using the Path list. The Path list holds up to 26 words.

1. Press (LIST).

Or, select `Path List` under the Commands menu. Then press (ENTER).

This is a sample Path list. If you haven't looked up any words, you see `No words in path`.

2. Press ⇧ to highlight a word.

To. . .	Press. . .
Define the word	(ENTER)
See thesaurus meaning	(⬭) + (T)

Saving Your Path List

Your Path list is automatically saved between sessions unless the batteries run out of power, or the Digital Book System is reset.

Words From Other Books

You can even look up words from other digital books. In this example, we'll look up a word from the *Video Companion* digital book.

1. Highlight a word in another digital book.

Read its User's Manual to learn how.

2. Press (2nd) plus (CARD).

3. Highlight the *Merriam-Webster® Advanced Dictionary* symbol. Then press (ENTER).

4. Press (ENTER) to see its definition(s).

5. To return to the other digital book, press (CARD). Highlight its symbol. Then press (ENTER).

About Receiving Words

The *Merriam-Webster® Advanced Dictionary* can receive only one or two words at a time from related digital books.

Sending Words to Other Books

The *Merriam-Webster® Advanced Dictionary* can also send words to related digital books. Here's how:

1. Highlight a word in the *Merriam-Webster® Advanced Dictionary.*
2. Press plus (CARD) .
3. Highlight the symbol of another digital book.
4. Press (ENTER) .

But, remember only related digital books can receive words from the *Merriam-Webster® Advanced Dictionary.*

Using Grammar Guide

This section shows
you how to find
grammar topics and
quiz exercises.

Finding Topics

You can find grammar information for any word in the *Merriam-Webster® Advanced Dictionary*. Press [2nd] + [G] at the entry line or when a word is highlighted to see a menu of relevant grammar topics.

1. At the main prompt, press [2nd] plus [G].

This is the main grammar menu. It lists all of the grammar topics.

2. Highlight a topic. Then press [ENTER].

Use [↑] or [↓] to move around.

3. Highlight a sub-topic. Then press [ENTER].

4. To see the next grammar topic, press [2nd] plus [DN] .

Picking Words in the Grammar Guide

Turn on pick mode by pressing [ENTER]. Highlight a word you want to see grammar information about. Then press [2nd] + [G].

You will either see a grammar topic menu or you'll go directly into the topic if there is only one.

Finding Topics by Typing

You can find topics by typing them in at the entry line. However, you must type in the topics exactly as they appear in the grammar guide or they will not be recognized.

For example, you can type `Apostrophe` . Then press [2nd] + [G]. to see any grammar information on apostrophes.

Grammar Exercises

Some Grammar Guide topics have exercises to help you sharpen your skills. Simply, press GAMES at a topic to see if any exercises are available.

Also, if you press 2nd + ↓ or read to the end of a chapter, you'll see a message if there are any grammar exercises available.

1. Type a word or pick one using pick mode.

2. Press 2nd + G . Then press ENTER.

3. Highlight a topic. Then press ENTER.

4. Highlight a sub-topic. Then press (ENTER).

5. At the topic, press (GAMES).

This screen shows you how to answer the questions, as they may vary from topic to topic.

6. Press (◯) plus (DN) to start the exercises.

Use the arrow keys to highlight the correct answer. Then press (ENTER). Press (◯) + (DN) to go to the next question. To see the previous question, press (◯) + (UP).

7. Press [2nd] plus [DN] after each question.

8. To see the correct answer, press ?.

Moving Around

You can view definitions, thesaurus meanings, Classmates (if any), Confusables (if any), and grammar guide topics from anywhere.

To...	Press..
See definition	[2nd] + [D] or [ENTER]
See thesaurus entry	[2nd] + [T]
See Classmates	[2nd] + [C]
See Confusables	[2nd] + [?*]
Go to grammar guide	[2nd] + [G]

Answering Correctly

When you answer all of the questions of a particular exercise correctly, you'll be rewarded with a little surprise.

Digital Book System

This section reviews
how to use
the Digital Book System.

Digital Book System

Installing & Removing Digital Books

To install a digital book, first turn off your Digital Book System. Then align the digital book's tabs with the notches in either book slot on the back and snap the book into the slot. If you install only one book, it doesn't matter which slot you use. But make sure that the book's metal contacts are facing down.

To remove a book, first turn off the Digital Book System. Then compress the book's tab and lift the book from the slot.

Restarting the Digital Book System

If the keyboard fails to respond or the screen performs erratically, first press (CLEAR) and then press (ON/OFF). If nothing happens, hold (CLEAR) and press (ON/OFF). If nothing happens still, press the recessed reset button on the back of your Digital Book System using a paper clip.

If you install or remove digital books when the Digital Book System is on, or when you reset the Digital Book System, you may erase information that you entered in the installed digital books.

Switching Between Digital Books

1. With two digital books installed, press CARD .

2. Highlight a symbol by pressing ⇨ or ⇦. Then press ENTER .

To return to the first book, repeat these steps.

Sending Words Between Books

Some digital books can send and receive words from other digital books.

1. Highlight a word in a digital book.

Read its User's Manual to learn how.

2. Hold ▭ and press CARD .

3. Highlight the other digital book's symbol. Then press ENTER .

You see its main display. You may have to press ENTER again to look up the word.

Replacing the Batteries

Your Digital Book System uses CR2032 lithium batteries. Have four new batteries ready before following these steps.

1. **Turn the Digital Book System off.**
2. **Press and slide the battery cover off the back of the unit. Then remove all batteries.**
3. **Place a battery, with its plus (+) sign up, at the bottom of each battery cavity.**
4. **Place a battery, plus sign up, at the top of each cavity. The metal clip must contact the top battery.**
5. **Replace the battery cover.**

To prevent deleting information from installed digital books:

- Always replace the batteries before they lose all power, and never remove the batteries while the Digital Book System is on.
- Never mix old and new batteries. And, once batteries have been removed, install new ones within two minutes.

Protecting the Digital Book System

- Don't touch the metal contacts on the back of your digital books or the rubber contacts in the book slots of the Digital Book System. **CAUTION:** Touching the contacts with statically charged objects, including your fingers, could erase information that you entered in your installed digital books.
- Don't put excessive pressure or weight on your digital books or Digital Book System.
- Don't expose your digital books to extreme or prolonged heat, cold, or other adverse conditions.

When you're not using your Digital Book System, keep two digital books or dummy books in its slots to prevent dust build-up.

Cleaning the Digital Book System

To clean the digital books, apply isopropyl alcohol with cotton swab.

To clean the Digital Book System, apply a mild household cleaner onto a soft cloth. **CAUTION:** Spraying liquids directly on your Digital Book System could damage its circuitry.

Specifications

Product Features

- 110,000 vocabulary words; 500,000 synonyms; 10,000 antonyms; 70,000 thesaurus meanings; 8,000 phrases; 3,000 etymologies and 11,000 Classmates
- Confusables™, phrases and hyphenation, MatchMaker™ II spelling correction, Crossword Solver, path list of up to 26 words, Pick Mode, and six typeface settings
- context-sensitive grammar guide, grammar exercises, backup (Query history), and screen-based menu system
- context-sensitive help information
- adjustable shutoff timing
- self-demonstration
- adjustable contrast
- ROM size: 2 megabytes

Copyrights, Trademarks and Patents

© 1991-1993 Franklin Electronic Publishers, Inc. All rights reserved.
© 1989 Merriam-Webster, Inc. . All rights reserved.

U.S. Patents 4, 490, 811; 4, 830, 618; 5, 007, 019; 5, 113, 340.
European Patent 0 136 379. Patents Pending.
ISBN 1-56712-027-X

Limited Warranty (U.S. only)

FRANKLIN warrants to you that the DIGITAL BOOK will be free from defects in materials and workmanship for one year from purchase. In the case of such a defect in your DIGITAL BOOK, FRANKLIN will repair or replace it without charge on return, with purchase receipt, to the dealer from which you made your purchase or Franklin Electronic Publishers, Inc., 122 Burrs Road, Mt. Holly, NJ 08060, within one year of purchase. Alternatively, FRANKLIN may, at its option, refund your purchase price. Data contained in the DIGITAL BOOK may be provided under license to FRANKLIN. FRANKLIN makes no warranty with respect to the accuracy of data in the DIGITAL BOOK. No warranty is made that the DIGITAL BOOK will run uninterrupted or error free. You assume all risk of any damage or loss from your use of the DIGITAL BOOK. This warranty does not apply if, in the sole discretion of FRANKLIN, the DIGITAL BOOK has been tampered with, damaged by accident, abuse, misuse, or misapplication, or as a result of service or modification by any party, including any dealer, other than FRANKLIN. This warranty applies only to products manufactured by or for FRANKLIN. Batteries, corrosion or battery contacts and any damage caused by batteries are not covered by this warranty. NO FRANKLIN DEALER, AGENT, OR EMPLOYEE IS AUTHORIZED TO MAKE ANY ADDITIONAL WARRANTY IN THIS REGARD OR TO MAKE ANY MODIFICATION OR EXTENSION OF THIS EXPRESS WARRANTY.

THE FOREGOING WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ALL OTHER EXPRESS OR IMPLIED WARRANTIES, WRITTEN OR ORAL, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. YOUR SOLE AND EXCLUSIVE REMEDY SHALL BE FRANKLIN'S OBLIGATION TO REPLACE OR REFUND AS SET FORTH ABOVE IN THIS WARRANTY. Some States do not allow the exclusion of implied warranties, or limitations on how long a warranty lasts. This warranty gives you specific rights; you may also have additional rights which vary from State to State. This warranty shall not be applicable to the extent that enforcement of any provision may be prohibited by applicable law.

FRANKLIN SHALL IN NO EVENT BE LIABLE TO YOU OR TO ANY OTHER PERSON FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, OR ANY OTHER INDIRECT LOSS OR DAMAGE, ARISING OUT OF YOUR PURCHASE, THE MANUFACTURE OR SALE OF THE DIGITAL BOOK, THIS LICENSE, OR ANY

OBLIGATION RESULTING THEREFROM OR THE USE OR PERFORMANCE OF THE DIGITAL BOOK UNDER ANY LEGAL THEORY, WHETHER BREACH OF CONTRACT, TORT, STRICT LIABILITY OR ANY OTHER CAUSE OF ACTION OR PROCEEDING, WHICH DAMAGES SHALL INCLUDE, BUT NOT BE LIMITED TO, LOST PROFITS, DAMAGES TO PROPERTY, OR PERSONAL INJURY (BUT ONLY TO THE EXTENT PERMITTED BY LAW). FRANKLIN'S ENTIRE LIABILITY FOR ANY CLAIM OR LOSS, DAMAGE, OR EXPENSE FROM ANY SUCH CAUSE SHALL IN NO EVENT EXCEED THE PRICE PAID FOR THE DIGITAL BOOK. THIS CLAUSE SHALL SURVIVE FAILURE OF AN EXCLUSIVE REMEDY.

This license and warranty is governed by the laws of the United States and the State of New Jersey.

Index

Arrow keys 14

Backing up at the entry line 21

Batteries
- replacing 35

Classmates
- finding 21

Commands menu 20

Confusable words
- finding 22

Dictionary entries
- antonyms 17
- derivative words 17
- etymology 17
- finding 15
- hyphenation points 17
- parts of speech 17
- synonyms 17
- understanding 17
- usage 17

Digital Book
- erasing information 5
- installation 5
- selecting 6

Digital Book System
- cleaning 36
- installing 33
- restarting 33
- switching between 34

Erasing letters 11

Finding

definitions
- by entering words 15
- by picking words 15

thesaurus entries
- by entering words 18
- by picking words 19
- by using GOLD key 19

Fonts
- selecting 7

Grammar guide
- finding topics 27

Gold key combinations 9

Grammar exercises
- answering 30
- finding 29
- move around in 31

Grammar guide
- exercises 29
- find next topic 28
- find topics by entering words 28
- moving around in 27
- picking words in 28

Help
using 9
Installing digital books 5
Keys
learn about 8
Look up words from other digital books 24
MatchMaker key 9
Fragment Finder™ 13
Menus
commands 20
Other 7
MORE key
understanding 17
ON/OFF key 5
Other menu 7
Path list
saving 23
using 23
Question mark, as Fragment Finder™ 12
Receiving words from other digital books 25
Resuming your session 6
Reviewing words 23
Selecting fonts 7
Sending words from other digital books 25
Shutoff timing, changing 7
Spell correction
with Letter Detective 12
Spelling correction
of misspelled words 11
tips 14
with Fragment Finder™ 13
Thesaurus entries
antonyms 19
Compares 19
finding 18
synonyms 19
understanding 19

Franklin®
Electronic Publishers
Mt. Holly, NJ 08060

FCR-28016-00 A PN 7201750 Printed in China